

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See instructions if interference to radio or television reception is suspected.

Radio and Television Interference

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

European Community

Complies with European Directive 89/336/EEC.

Disposal of Your Old Product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC. Please inform your self about the local separate collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.



Disposal of Flat Batteries / Accumulators

You, as the end user, are legally obliged (Battery Ordinance) to return all flat batteries and rechargeable batteries. Disposal in the household waste is prohibited. "European Directive 2006/66/EC" Batteries, including rechargeable batteries, which contain hazardous substances are marked by symbols which indicate the prohibition of disposal in the household waste.

The designations for the heavy metals concerned are as follows: Cd = cadmium, Hg = mercury, Pb = lead. You can return flat batteries/rechargeable batteries free of charge to the collection points in your community or anywhere else where batteries / rechargeable batteries are sold. You thus fulfil your statutory obligations and help protect the environment.

Salubrion, LLC Limited Warranty

This limited warranty extends to original consumer purchaser or any person receiving this product as a gift from the original consumer purchaser and to no other purchaser or transferee.

Limited One (1) Year Warranty

Salubrion warrants this product against defects in materials or workmanship for a period of one (1) year after the date of original retail purchase. During this period, Salubrion will repair or replace a defective product or part, at their discretion, with a new or refurbished product or part without charge to you. You must deliver the entire product to Salubrion. You are responsible for all transportation and insurance charges for the unit to and from the Salubrion's Service Center.

Your Responsibility

The above warranty is subject to the following conditions: (1) You must retain your bill of sale or provide other proof of purchase. (2) You must notify Salubrion within thirty (30) days after you discover a defective product or part. (3) All warranty servicing of this product must be made by Salubrion or a Salubrion Authorized Service Station. (4) Salubrion warranties are effective only if the product is purchased and used in the same continent territorial regions. (5) Warranties extend only to defects in materials or workmanship as limited above and do not extend to any product or parts which have been lost or discarded by you or to damage to products or parts caused by misuse, accident, damage caused by Acts of God, improper maintenance or use in violation of instructions furnished by us; or to products which have been altered or modified. (6) A physically damaged product is not acceptable for repair or exchange whether in or out of warranty and will be returned as received.


enso
ASARI™

Welcome!


Changing the Batteries

The Enso Asari requires two lithium coin cell batteries.

Battery Size: **CR2032**



- 1 Slide battery bar to side.
- 2 Remove old battery.
- 3 Insert new CR2032 battery. Positive (+) side facing out.
- 4 Slide bar back over battery.



enso
ASARI™

Enso, the Japanese word for *circle*, is a symbol of enlightenment, elegance, and the universe that is drawn with a single clockwise brushstroke.



During a timer, the **Enso Ring** is slowly *brushed* around the display. This subtle presentation of time frees your mind from the distracting thought of numerical minutes and seconds. The timer gently concludes with soothing chimes of singing bowls.

Asari is a small clam found in the waters off Japan. Its diminutive size and sculpted shell inspired the design of the salubrion **Enso Asari**.

Thank you!




salubrion™
www.salubrion.com

Setting the Clock

- 1 Press Clock Button.
- 2 Adjust the Clock time. Use the **enCircle**.
- 3 Press Center Button to toggle 12/24-hour format and set seconds to zero.
- 4 Press Clock Button.

The enCircle Touch Pad



Move your finger around the **enCircle** Touch Pad to increase or decrease the selected time.

Setting the Alarm

- 1 Press Alarm Button.
- 2 Adjust the Alarm time. Use the **enCircle**.
- 3 Press Alarm Button to set Alarm.
- X Once Alarm is set, press Alarm Button to cancel.
- When Alarm Triggers
 - Press Center Button to Snooze.
 - Press Alarm Button to turn Alarm off.

Setting the Timer

- 1 Press Timer Button.
- 2 Adjust the Timer. Use the **enCircle**.
- 3 Press Center Button to start Timer.

Timer Modes


The Timer can be configured with the following options:

Countdown Min:Sec	Repeat Min:Sec
Countdown Hour:Min	Repeat Hour:Min

Press and hold the Timer Button to cycle through the timer modes.

Stopwatch Mode

Set Timer to 0:00. Press Center Button to start Timer in count-up mode.



Setting the Chime

Press Audio Button to cycle through three volume levels of two sounds. The selected sound setting applies to the Timer and Alarm.

Using the Backlight

Press Center Button to turn on the backlight for three seconds. Due to power limitations the backlight cannot always remain on.

Hiding Timer Display

When Timer is running, hold down Center Button for one second to hide the timer, leaving only the Enso Ring.